
CONTROL, DOOR AND DRAWER PARTS
For Models: KEWD105HWH3, KEWD105HBL3, KEWD105HBT3, KEWD105HSS3
(White) (Black) (Biscuit) (Stainless Steel) (Stainless Steel)




CONTROL, DOOR AND DRAWER PARTS

For Models: KEWD105HWH3, KEWD105HBL3, KEWD105HBT3, KEWD105HSS3 (White) (Black) (Biscuit) (Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--------------------|
| 1 | | Literature Parts |
| ' | LIT8300562 | Tech Sheet |
| | LIT8300560 | Use & Care Guide |
| | LIT8300561 | Installation |
| | 2110000001 | Instructions |
| 2 | 4453042 | Panel, Control |
| 2 3 | 4453049 | Escutchen, Control |
| Ŭ | 1 1000 10 | Panel |
| 4 | 4452824 | Light, Indicator |
| 5 | 4452841 | Switch, Rocker |
| • | | SPST Illuminated |
| 6 | 4452842 | Switch, Rocker |
| • | | SPST |
| 7 | 4455984 | Knob, Thermostat |
| 8 | 4453039 | Gasket, Drawer |
| 9 | 4452979 | Drawer Assembly |
| 10 | 4453106 | Adapter |
| 11 | 8301004 | Liner, Drawer |
| 12 | 4452820 | Knob, Ball |
| 13 | 4452830 | Label, Moist/Dry |
| 14 | | Door, Front Assy |
| | 4453016 | Black |
| | 4453017 | White |
| | 4453018 | Biscuit |
| | 4453019 | Stainless Steel |
| 15 | 8301005 | Vent, Slide |
| 16 | | Handle, Drawer |
| | 4452502 | Black |
| | 4452503 | White |
| | 4452871 | Biscuit |
| | 4452088 | Stainless Steel |
| 17 | 2005292 | Name Plate |
| | | (Stainless Model) |
| 18 | 4452821 | Rack, Warming |
| 19 | 4453107 | Palnut |
| 20 | | Cover, Pan |
| | 4452853 | Large, (Half) |
| | 4452854 | Small (1/3) |
| 21 | | Pan, Warming |
| | 4452849 | Large (Half) |
| | 4452850 | Small (1/3) |
| 22 | 3400805 | Screw, 8-18 x 3/8 |
| 23 | 3196184 | Screw, 8-32 x 9/16 |
| 24 | 4456038 | Insulation |

INTERNAL WARMING DRAWER PARTS

For Models: KEWD105HWH3, KEWD105HBL3, KEWD105HBT3, KEWD105HSS3 (White) (Black) (Biscuit) (Stainless Steel)



INTERNAL WARMING DRAWER PARTS

For Models: KEWD105HWH3, KEWD105HBL3, KEWD105HBT3, KEWD105HSS3 (White) (Black) (Biscuit) (Stainless Steel)

| Illus. No. | Part No. | DESCRIPTION | |
|------------------------------------|-------------|-------------------|--|
| | | | |
| 1 | 4453065 | Top, Wrapper | |
| 2 | 4453100 | Panel, Service | |
| 3 | 4453150 | Plate, Element | |
| | | Mounting | |
| 4 | 4452154 | Element, Broil | |
| 5 | 4452595 | Back, Wrapper | |
| 6 | 4450934 | Thermostat | |
| 7 | 4452822 | Timer Assembly | |
| 8 | 4456037 | Bracket, Mounting | |
| | | Thermostat | |
| 9 | 4456032 | Thermostat, | |
| | | Bi-Metal | |
| 10 | 4456049 | Clip, Thermostat | |
| 11 | 4456046 | Bracket, Mounting | |
| 12 | 4453045 | Wrapper | |
| 13 | | Slide Assembly | |
| | 4452878 | Left Hand | |
| | 4452877 | Right hand | |
| 14 | 4453048 | Bracket, Control | |
| 15 | 3400805 | Screw, 8-18 x 3/8 | |
| 16 | 4449809 | Screw, 8-18 x 3/8 | |
| 17 | 313806 | Screw, 6-32 x 3/8 | |
| FOLLOWING PARTS NOT ILLUSTRATED | | | |

WIRING HARNESS PARTS

4452825 Harness, Wire (Main) 4452886 Power Cord 4452601 Strain Relief 4450800 Screw, Ground (Power Cord)

INSULATION

4453198 Insulation

Miscellaneous

4448950 Mounting Screws(2)